


DH Research Accessory Instructions: Laser Module

Should you purchase other accessories from DH Research, here would be the instructions on how to set up those accessories to the DH Research Flight Controller.

1.1 Laser Module (Range of a survey instrument is 0.05~15m)

1.1.1 Connect the cable to the port "+5V Tx5 Rx5 -" on the Flight Controller as shown below:



1.1.2 The glass surface of the laser module should face the direction against which we want to measure from, for example, to the ground in order to keep the flight at a constant height.

1.1.3 Connect the Flight Controller to Mission Planner with USB cable or telemetry radio

- Under **CONFIG | Full Parameter Tree**, make sure SERIAL5_PROTOCOL equals 5 and RNGFND1_TYPE equals 10.

